







### WIRELESS MICROPHONE RECEIVER




DVD PLAYER




CDG PLAYER




VCR PLAYER




Karaoke Mixer KP-600



Power Amplifier MA-1200



WS-6215




WS-6215

### UNBALANCE CABLE



1/4

RCA



Two Way Crossover  
Connection Type: Speakon